



# INSTALLATION INSTRUCTION

## LED RECHARGEABLE LIGHT

### SPECIFICATIONS



Model	VT-11-R
Watts	10
Lumens	700
BeamAngle	100
PF	>0.9
CRI	>80
LED Chip Type	SMD
IP Rating	IP44
Unit Color	Green+Black
On/Off Cycles	>15000
Operation Temperature	-20°C to +45°C
Input Power	AC:100-240V
Dimension	175x125mm

### INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installing and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best.

The warranty is valid for 2 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.

**2** YEAR  
WARRANTY\*





## Safety instructions for batteries and chargers

### Batteries

1. Never attempt to open for any reason.
2. Do not store in locations where the temperature may exceed 40 °C.
3. Charge only at ambient temperatures between 4 °C and 40 °C.
4. Charge only using the charger provided with the tool.
5. When disposing of batteries, follow the instructions given in the section "Protecting the environment".
6. Do not cause short circuits. If connection is made between the positive (+) and negative (-) terminal directly or via accidental contact with metallic objects, the battery is short circuited and an intense current will flow causing heat generation which may lead to casing rupture or fire.
7. Do not heat. If batteries are heated to above 100 °C, sealing and insulating separators and other polymer components may be damaged resulting in electrolyte leakage and/or internal short circuiting leading to heat generation causing rupture or fire. Moreover do not dispose of the batteries in fire, explosion and/or intense burning may result.
8. Under extreme conditions, battery leakage may occur. When you notice liquid on the battery, proceed as follows:
  - Carefully wipe the liquid off using a cloth. Avoid skin contact.
  - In case of skin or eye contact, follow the instructions below:
    - i. Immediately rinse with water. Neutralize with a mild acid such as lemon juice or vinegar.
    - ii. In case of eye contact, rinse abundantly with clean water for at least 10 minutes. Consult a physician.

**Fire hazard!** Avoid short-circuiting the contacts of a detached battery. Do not incinerate the battery.

### Chargers

1. Use the charger provided with the tool only to charge the battery
2. Never attempt to charge non-rechargeable batteries.
3. Have defective cords replaced immediately.
4. Do not expose to water.
5. Do not open the charger.
6. Do not probe the charger.
7. The charger is intended for indoor use only.

## Safety warning for work-Light

This is not a toy; children should not permit to use it.  
This is a DIY product, all electronic parts fixed already,  
any intention of opening work-light or changing  
work-light design is prohibitive unless a professional  
electrician.

Do not attempt to replace or change or the diode lights!  
If the protective glass is cracked or broken, it must be  
replaced before the work light can be used again.

## Symbology

	Double insulated
	Underwriters Laboratories, Inc.
	Volts Alternating Current
	Amperes

## Major Components

1. Work light head
2. LED lamp assembly
3. Portable bracket
4. Protective cover
5. USB socket
6. Micro socket
7. LED indicator
8. ON/OFF switch with mode function



Fig. 1



Fig. 2

## Assembly Instruction



### ADJUSTMENT THE STAND

The LED work light's portable bracket (3) is adjustable (Max. 45°). Adjust the bracket to the suitable position before using.

**NOTE:** Do not exceed to adjustable range which avoid damaging the bracket

## OPERATION

### CHARGING THE WORK LIGHT

1. Open the protective cover (4) and push the micro plug (a) into micro socket (6).
2. Plug the adapter into a suitable mains outlet. Do not use an extension cord.
3. When the battery is loaded, three LED indicators (7) all illumine (Red light, yellow light and green light light up in sequence).

**NOTE:** Reset the protective cover after full charge which to avoid water enter. (Refer to Fig. 2)

**NOTE:** The LED indicator only will show red that means it's batteries will soon run out and need to recharge.

**NOTE:** Don't turn the work light on/ use USB while charging.



Fig. 4

### USB OUTPUT

The USB DC 5V 1A output socket (8) can use for all kinds of device which can be charged by USB cord (b), such as mobile phone, MP3/MP4, Bluetooth headset etc.

**NOTE:** The USB output will stop output automatically if the total working current of the total connected device exceed the limit.



Fig. 5

### SWITCH ON/OFF AND LUMEN ADJUSTMENT (See Fig. 2)

The work light is equipped with an ON/OFF switch with mode function (8) locate on the back side of the work light.

The LED work light's brightness is adjustable.

With press ON/OFF switch (8): 1st press: 100% brightness; 2nd press: 50% brightness; 3rd press: SOS flashing; 4th press: OFF.

**Discharging time:** About 3 hours for 100% brightness;  
About 5 hours for 40% brightness;

### WARNING!

- To reduce the risk of injury, user must read and understand instruction manual.
- Always make sure the work light is off and complete cool before attempting to clean it.