

WEEE Number: 80133970

INSTALLATION INSTRUCTION TABLE LAMP

TECHNICAL DATA

VT-7522
2W
200LM
180°
1 Meter
DC:5V, 1A~2A
Aluminium
78.5x386mm
4400mA
6-8 Hours
8-10 Hours
10~100%



INTRODUCTION

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. This product is warranted for manufacturing defects only.

WARNING!


1. Please make sure to turn off the power before starting the installation

2. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.



MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.



This marking indicates that this product should not be disposed of with other household wastes.



Caution, risk of electric shock.

OPERATION CAUTIONS:

1. Please do not put the lamp on the high-temperature surfaces, and do not use it in flammable or humid environment, to avoid the breakdown, short circuit etc.

- 2. The adapter must be under the specialized range.
- 3. Please ensure to place the lamp on a steady base only.

OPERATION GUIDE

- 1. Connect the charging base into adapter[not included]
- 2. Connect the adapter[not included] into power source
- 2. Connect the charging base into the table lamp
- 3. Tap on the button at the top of lamp to switch on/off the lamp

4. For Dimming function - Make sure the light is ON, tap on the touch button and hold for the light to increase the brightness. When turning on the lamp next time, the light brightness level will be the same as the last setting.

COLOR LED INDICATOR


- 1. **RED COLOR INDICATOR** Charging is in progress.
- 2. GREEN COLOR INDICATOR The battery is full charge


MAINTENANCE

1. Please clean the lamp once in every two months to keep it smooth and bright.

- 2. Use cleaning cloth and water to clean the dust
- 3. For filthy marks, please use cleaning cloth and soapsuds.
- 4. Please do not clean the lamp by high-volatility and

high-corrosive liquid which can lead to discoloring or damaging the lamp.





IN CASE OF ANY OUERY/ISSUE WITH THE PRODUCT, PLEASE REACH OUT TO US AT: SUPPORT@V-TAC.EU MORE PRODUCTS RANGE, INQUIRY PLEASE CONTACT OUR DISTRIBUTOR OR NEAREST DEALERS. V-TAC EUROPE LTD. BULGARIA, PLOVDIV 4000, BUL.L.KARAVELOW 9B